

# Light-O-Rama




ShowTime  
MP3 Director  
Show Director with MP3 Player

**DC-MP3**

[www.lightorama.com](http://www.lightorama.com)

- Plays MP3s while directing a network of Light-O-Rama controllers
- Stereo line outputs to drive your audio system
- Eliminates the need for a Windows PC to run shows
- Uses an SD card to store animation sequences and MP3 music files
- Can be used standalone or fits inside and is powered by an LOR1602W lighting controller
- Use the Light-O-Rama Showtime Windows software to construct complex shows with musical and non-musical animations and then transfer the shows to an SD card
- Runs the SD card shows continuously as long as the card is inserted and the DC-MP3 is powered
- On board real time clock with powerfail backup can be programmed to schedule up to nine shows
- Six trigger inputs allow external events to start one of six shows



**DC-MP3 director card shown with SD card inserted**  
5 3/8" w x 3/4" h x 3" d

Now you can run your shows without a Windows PC. Great for commercial and/or outdoor applications where there is no place for a Windows PC. Also great for Halloween applications using the input triggers to start a show. The MP3 Director will play the lighting animation sequence files and their associated MP3 audio files.

SD cards up to 2 GB are supported. For 128Kbs encoded MP3 music files and average size corresponding sequence files, a 128 MB SD card will hold about an hour of lighting commands and audio.

Pop out the SD card at any time and insert another to switch shows and/or schedules. The MP3 Director will start the new SD card shows when the card is inserted, as specified by the schedules and/or in response to input triggers.

Can be powered by a controller, so you just turn on power to the controller to start the show. Or, it can be powered by a 12VDC power brick that you can turn on and off to control the show.



**LOR1602MP3 package**  
Shown with cover removed

**Includes 128 MB SD card and  
USB SD card reader/writer for PC**

Compatible SD Cards	Lexar Media
	SimpleTech

Light-O-Rama, Inc.  
Tel: (518) 539-9000 Fax (518) 538-0067  
[info@lightorama.com](mailto:info@lightorama.com)