# Gen3 Input Header

Used with Gen3 LOR16xx controllers and the Gen3 MP3 ShowTime Director.

Input header plugs into the black, 10 pin connector

+5VDC (100mA) and +9VDC (150mA) outputs
Note: Use is optional

Connect one side of each switch to G (ground)

Switch for Trigger 1

Switch for Trigger 2

Note: Inputs I1 thru I3 can be used on any controller. Inputs I4 thru I6 are only active when connected to a device with a MP3 Director.

Connect the other side of the switch to one of the input connectors (marked I1 thru I6)