



Connect Switches between Ground (G) and A1 thru A6 for Inputs 1 thru 6.



Light-O-Rama MP3-Connector